MIDDLETON RAILWAY TRUST LTD

STEAM LOCOMOTIVE EXAMINATION REPORT



Examination C (every 30 days use – to be carried out in steam and cold, as required)

			LOCOMOTIVE No.					
No	Item	Tick	Comments					
Boiler								
1	Check firebox for water/steam leaks							
2	Remove and inspect fusible plugs, Renew, if necessary (record this)							
3	Check condition of tube ends in firebox							
4	Check firebox stays for breakage, wastage, etc							
5	Check water spaces for scale and sludge							
6	Check smokebox for water/steam leaks and for signs of air leakage							
7	Check tube condition of tube ends in smokebox							
8	Check condition of securing dart for smokebox door							
9	Check blower ring and any other smokebox pipework for condition and security							
10	Check for leaks on all visible seams of boiler, washout plugs, mudholes, etc							
11	Check condition of ashpan and dampers, including linkages							
Fittir	Fittings & Pipework							
12	Check injectors, whistle, blower, etc for satisfactory operation							
13	Check safety valve for correct operation and record pressure							
14	Check each water gauge for correct operation							
15	Check all pipework and valves for leakage, damage and chaffing							
Cylinders & Motion								
16	Check crossheads for wear, security, including small end fastenings and							
17	piston rod cotters Check slidebars for loose mounting bolts and that all pins and cotters are present and secure							
18	Check connecting rods for security of cotters and retaining screws and wear							
19	in bearings Check Coupling rods for security of							
	cotters and retaining screws and wear in bearings							
20	Check valve gear pins for security, lubrication and general wear							
21	Check reversing lever for wear of quadrant plate and catch.							
22	Check operation of drain cocks and for leakage when closed							
23	Check all glands and covers for steam leakage							

24	Check valves and pistons for						
	excessive steam leakage as an						
	indication of worn or damaged rings						
and valve faces.							
Brakes							
25	Check brakes for correct operation, adjustment, missing pins and security						
26	Check all brake hangers for wear and security						
27	Check condition of all brake blocks						
28	Check vacuum brake system for correct operation						
29	Check vacuum brake hoses for						
30	abrasion and missing sealing rubbers Check vacuum brake pipework						
30	generally for security, damage and						
	leakage						
Fram	es, Wheels and Axleboxes						
31	Check hornstays for condition and						
	loosenes						
32	Check axlesboxes for general condition and wear						
33	Check frames and stretchers for damage, loose fastenings, cracks, etc.						
34	Check springs for broken or missing						
	leaves and security						
	Check all wheel tyres for condition						
Buffers & drawgear							
35	Check couplings for damage, missing pins and security						
36	Check buffers for damage and security						
Gene	ral						
37	Check cab and bunker for damage, looseness, etc						
38	Check water tank for damage, looseness, leaks, etc						
39	Check chains on Sentinel locos for condition of split pins and removable link.						
	Locomotive suitable for continue	ed service	YES	NO			
If no	o, list work to be carried out before		~				
loco can be returned to service							
1000	can be returned to service						
SIGNED		DATE					